

Installation, Operating & Maintenance Instructions




Variable leak valve DN 16 (5/8") with integrated controller with RS232 interface

Series 590 DN 16 mm (I.D. 5/8")

This manual is valid for the following product ordering number:

59024-.EGG-....

configured with firmware **600P.1G.21.00**



Sample picture

Imprint

Manufacturer VAT Vakuumventile AG, CH-9469 Haag, Switzerland

Website: www.vatvalve.com

Phone: +41 81 771 61 61

Fax: +41 81 771 48 30

Email: CH@vatvalve.com

Publisher VAT Vakuumventile AG, CH-9469 Haag, Switzerland

Editor VAT Vakuumventile AG, CH-9469 Haag, Switzerland

Print VAT Vakuumventile AG, CH-9469 Haag, Switzerland

Copyright © VAT Vakuumventile AG 2016

No part of these Instructions may be reproduced in any way (photocopies, microfilms or any other reproduction processes) nor may it be manipulated with electronic systems, duplicated or distributed without written permission from VAT. Offenders are liable to pay damages.

The original VAT firmware and updated state of the art versions of the VAT firmware are intended for use with VAT products. The VAT firmware contains a limited, time unlimited user license. The VAT firmware may not be used for purposes other than those intended nor is it permitted to make copies of the VAT firmware. In particular, it is strictly forbidden to give copies of the VAT firmware to other people.

The use of trade names, brand names, trademarks, etc. in these Instructions does not entitle third parties to consider these names to be unprotected and to use them freely. This is in accordance with the meaning of the laws and acts covering brand names and trademarks.

Contents

1	Description of product.....	5
1.1	Identification of product	5
1.2	Use of product	5
1.3	Used abbreviations.....	5
1.4	Related documents.....	5
1.5	Important information.....	5
1.6	Technical data	6
1.6.1	Control and actuating unit.....	6
1.6.2	Valve unit.....	7
2	Safety	8
2.1	Compulsory reading material.....	8
2.2	Danger levels	8
2.3	Personnel qualifications.....	9
3	Design and Function.....	10
3.1	Design	10
3.2	Function.....	10
4	Installation	11
4.1	Unpacking	11
4.2	Installation into the system	12
4.2.1	Installation space condition.....	13
4.2.2	Connection overview.....	14
4.2.3	Installation procedure.....	15
4.2.4	Admissible forces.....	15
4.2.4.1	Admissible forces at controller.....	15
4.3	Electrical connection.....	16
4.3.1	Ground connection	17
4.3.2	Sensor supply concepts.....	18
4.3.3	Power and sensor connection (+24 VDC sensors)	19
4.3.3.1	Sensor power wiring via controller.....	19
4.3.3.2	Sensor power wiring external	20
4.3.4	Power and sensor connection (± 15 VDC sensors) without opt. SPS module..	21
4.3.4.1	Sensor power wiring via controller.....	21
4.3.4.1	Sensor power wiring external	22
4.3.5	Service port connection	23
4.4	RS232 interface.....	23
4.4.1	Settings.....	23
4.4.2	RS232 Schematics	23
4.4.2.1	Configuration with switches for digital inputs	24
4.4.2.2	Configuration with voltage source for digital inputs	25
4.4.2.3	Digital inputs.....	26
4.5	Initial operation	27
4.5.1	Setup procedure	27
4.5.2	RS232 Interface configuration	27
4.5.3	LOGIC I/O configuration	29
4.5.4	Valve configuration	30
4.5.5	Sensor configuration.....	30
4.5.6	ZERO.....	31
4.5.7	Fixed PI upstream configuration	32
4.5.7.1	Position Limit open adjustment.....	33
4.6	Tuning of control performance.....	33
4.6.1	Tuning of control performance with fixed PI pressure controller	34
4.6.1.1	Optimizing P gain and I gain.....	34

4.7	RS232 interface commands	37
4.7.1	RS232 command syntax	37
4.7.2	Control commands	37
4.7.3	Inquiry commands	38
4.7.4	Position Limit open (setup command)	42
4.7.5	Setup commands	43
4.7.5.1	Overview pressure controller	50
4.7.6	Pressure control algorithm	51
4.7.6.1	Adaptive control algorithm (downstream)	51
4.7.6.2	Fixed 1 control algorithm (default fixed PI upstream)	53
4.7.6.3	Fixed 2 control algorithm	54
4.7.6.4	Soft pump control algorithm	55
4.7.7	Error messages	56
5	Operation.....	57
5.1	Normal operation	57
5.1.1	Local operation.....	57
5.1.2	Remote operation.....	58
5.2	Close valve	58
5.3	Open valve.....	58
5.4	Position control	59
5.5	Pressure control.....	59
5.6	Display information	60
5.6.1	Power up.....	60
5.6.2	Operation	61
5.6.3	Errors	61
5.6.4	Safety mode	61
5.7	Operation under increased temperature	62
5.7.1	Bake-out.....	62
5.8	Behavior during power up.....	63
5.9	Behavior during power failure	63
5.10	Trouble shooting	64
6	Maintenance	66
7	Repairs	67
7.1	Replacement of diaphragm.....	68
8	Dismounting and Storage	70
8.1	Dismounting.....	70
8.2	Storage	71
9	Packaging and Transport.....	72
9.1	Packaging	72
9.2	Transport	73
10	Disposal.....	74
11	Spare parts.....	75
12	Appendix	76

1 Description of product

1.1 Identification of product

The fabrication number and order number are fixed on the product directly or by means of an identification plate.



1.2 Use of product

Use product for clean and dry vacuum applications only. Other applications are only allowed with the written permission of VAT.

1.3 Used abbreviations

Abbreviation	Description
CPA	Control Performance Analyzer

1.4 Related documents

- Product data sheet
- Dimensional drawing

1.5 Important information



This symbol points to a very important statement that requires particular attention.

Example:



VAT disclaims any liability for damages resulting from inappropriate packaging.

1.6 Technical data

1.6.1 Control and actuating unit

Description		
Input voltage ¹⁾	+24 VDC ($\pm 10\%$) @ 0.5 V pk-pk max.	[connector: POWER]
Power consumption	38 W	[connector: POWER]
Sensor power supply output ²⁾	+24 VDC / 1500 mA max.	[connector: SENSOR]
Sensor input Signal input voltage / Input resistance ADC resolution Sampling time	0-10 VDC / $R_i > 100 \text{ k}\Omega$ 0.23 mV 10 ms	[connector: SENSOR]
Ambient temperature	0 °C to +50 °C max. (<35 °C recommended)	
Pressure control accuracy	5 mV or 0.1% of setpoint, whichever is greater	
Position resolution / position control capability	100'000 (full stroke)	
Typical closing / opening time	3.5 s	

¹⁾ Internal overcurrent protection by a PTC device.

²⁾ Refer to chapter «Sensor supply concepts» for details.

1.6.2

Valve unit



Please refer to Product data sheet.

2 Safety

2.1 Compulsory reading material

Read this chapter prior to performing any work with or on the product. It contains important information that is significant for your own personal safety. This chapter must have been read and understood by all persons who perform any kind of work with or on the product during any stage of its serviceable life.

	NOTICE
	<p>Lack of knowledge Failing to read this manual may result in property damage. Firstly, read manual.</p>



These Installation, Operating & Maintenance Instructions are an integral part of a comprehensive documentation belonging to a complete technical system. They must be stored together with the other documentation and accessible for anybody who is authorized to work with the system at any time.

2.2 Danger levels



	⚠ DANGER
	<p>High risk Indicates a hazardous situation which, if not avoided, will result in death or serious injury.</p>

	⚠ WARNING
	<p>Medium risk Indicates a hazardous situation which, if not avoided, could result in death or serious injury.</p>

	⚠ CAUTION
	<p>Low risk Indicates a hazardous situation which, if not avoided, may result in minor or moderate injury.</p>



	NOTICE
	<p>Command Indicates a hazardous situation which, if not avoided, may result in property damage.</p>

2.3 Personnel qualifications

	<p data-bbox="858 383 1114 427"> WARNING</p> <p data-bbox="547 443 794 472">Unqualified personnel</p> <p data-bbox="547 481 1267 548">Inappropriate handling may cause serious injury or property damage. Only qualified personnel are allowed to carry out the described work.</p>
---	--

3 Design and Function

3.1 Design





mechanical position indicator


3.2 Function


The valve plate acts as a throttling element and varies the conductance of the valve opening. Actuation is performed with a stepper motor and controller. The stepper motor/controller version ensures accurate pressure control due to exact gate positioning.


4 Installation

	 WARNING
	<p>Unqualified personnel Inappropriate handling may cause serious injury or property damage. Only qualified personnel are allowed to carry out the described work.</p>

4.1 Unpacking

	NOTICE
	<p>Physical overstraining at controller Inappropriate handling with the valve may cause in damage of controller. Do not place the valve on the controller panel.</p>

	NOTICE
	<p>Damage of valve and flanges Inappropriate handling with the valve may cause in damage of controller. Pay attention that valve and flanges don't get damaged when the valve is lifting out of the box and handled afterwards.</p>

	NOTICE
	<p>Contamination Plate and other parts of the valve must be protected from contamination. Always wear clean room gloves when handling the valve.</p>



- Make sure that the supplied products are in accordance with your order.
- Inspect the quality of the supplied products visually. If it does not meet your requirements, please contact VAT immediately.
- Store the original packaging material. It may be useful if products must be returned to VAT.

1. Open the transport case and remove inside packing material as far as necessary.
2. Lift the valve carefully and place it on a clean place.



Do not remove protective foils from valve opening

4.2 Installation into the system

	NOTICE
	<p>Sealing surfaces</p> <p>Sealing surfaces of valve and vacuum system could be damage in case of incorrect handling.</p> <p>Only qualified personal are allowed to install the valve into the vacuum system.</p>

	NOTICE
	<p>Wrong connection</p> <p>Wrong connection may result in damage of controller or power supply.</p> <p>Connect all cables exactly as shown in the following descriptions and schematics.</p>

	NOTICE
	<p>Burned connector pins (spark)</p> <p>Connector pins or electronic parts could damage, if plugged and unplugged under power.</p> <p>Do not plug or unplug connectors under power.</p>


	NOTICE
	<p>Contamination</p> <p>Plate and other parts of the valve must be protected from contamination.</p> <p>Always wear clean room gloves when handling the valve.</p>

Mount valve to a clean system only.

4.2.1 Installation space condition




Install the valve with integrated controller with space for dismantling and air circulation as shown in figure below.




4.2.2 Connection overview

System:



- 1 Valve
- 2 Process chamber
- 3 Gas inlet
- 4 Controller
- 5 Pressure sensor
- 6 Sensor cable
- 7 Cable to remote control unit (RS232)
- 8 Cable to power supply
- 9 Pump

Controller:



4.2.3 Installation procedure

1. Remove protection flanges only prior assembly into the vacuum system.
2. Install valve [1] into the vacuum system.



- The valve seat side is indicated by the symbol «Δ» on dimensional drawing, see also «Installation space condition».
- Do not admit higher forces to the valve than indicated under «Admissible forces».
- Make sure that enough space is kept free to do preventive maintenance work. The required space is indicated on the dimensional drawing.

3. Install the sensor [5] according to the recommendations of the sensor manufacturer and directives given under «Requirements to sensor connection».
4. Connect pressure sensor cable [6] to sensor and then to valve (connector: SENSOR). Refer to chapter «Electrical connection» for correct wiring. 59024-.EGG-.... supports 1 sensor.
5. Connect valve to RS232 [7] (connector: INTERFACE). Refer to «RS232 schematics» for correct wiring.
6. Connect power supply [8] to valve (connector: POWER). Refer to chapter «Electrical connection» for correct wiring.




To provide power to the valve motor pins 4 and 8 must be bridged, otherwise motor interlock is active and the valve enters the safety mode and is not operative. Refer also to «Safety mode».

7. Perform «Setup procedure» to prepare valve for operation.




Without performing the setup procedure the valve will not be able to do pressure control.


4.2.4 Admissible forces


	NOTICE
	<p>Force at valve body and flange</p> <p>Forces from the weight of other components can lead to deformation of the valve body and flanges.</p> <p>Do not apply any force at valve body or flanges.</p>

4.2.4.1 Admissible forces at controller

	NOTICE
	<p>Force at controller</p> <p>Forces from the weight of other components can lead to deformation the controller.</p> <p>Do not apply any force at controller.</p>

4.3 Electrical connection


	NOTICE
	<p>Wrong connection</p> <p>Wrong connection may result in damage of controller or power supply. Connect all cables exactly as shown in the following descriptions and schematics.</p>

	NOTICE
	<p>Burned connector pins (spark)</p> <p>Connector pins or electronic parts could damage, if plugged and unplugged under power. Do not plug or unplug connectors under power.</p>

4.3.1 Ground connection

Recommendation for ground strap between controller and system (chassis)

Material	L (Length max.)	B1 (min.)	B2 (min.)	d1 (Ø)	d2 (Ø)
copper tinned	200 mm	25 mm	25 mm	4.5 mm	customized



- Connection plates of ground strap must be total plane for a good electrical contact!
- The connection point at chassis (FE) must be blank metal (not coated). It is also possible to connect the ground strap at system chamber if it is well connected to PE.
- Avoid low chassis cross section to the system PE connection. (min. same cross section as ground strap)

4.3.2 Sensor supply concepts


This valve offers 2 alternative concepts to supply the sensor(s) with power. This depends on the sensor type and valve version that is used.

Concepts:

- External +24 VDC supplied to POWER connector is feedthrough to SENSOR connector to supply 24 VDC sensors. Refer to chapter «Power and sensor connection (+24 VDC sensors)» for schematic and correct wiring.
- External ± 15 VDC supplied to POWER connector is feedthrough to SENSOR connector to supply ± 15 VDC sensors. Refer to chapter «Power and sensor connection (± 15 VDC sensors) without optional SPS module» for schematic and correct wiring.

4.3.3 Power and sensor connection (+24 VDC sensors)

4.3.3.1 Sensor power wiring via controller




Pins 4 and 8 must be bridged for operation. An optional switch would allow for motor interlock to prevent valve from moving.



- Use shielded sensor cable(s). Keep cable as short as possible, but locate it away from noise sources.
- Connect Power supply (+24 / GND) at DB-9 male power connector and Sensors (+24V / 0V / + / -) at DB-15 female sensor connector exactly as shown in the drawing above!
- Connector: Use only screws with 4-40 UNC thread for fastening the connectors!

4.3.3.2 Sensor power wiring external



Pins 4 and 8 must be bridged for operation. An optional switch would allow for motor interlock to prevent valve from moving.




- Use shielded sensor cable(s). Keep cable as short as possible, but locate it away from noise sources.
- Connect Power supply (+24 / GND) at DB-9 male power connector and Sensors (0V / + / -) at DB-15 female sensor connector exactly as shown in the drawing above!
- Connector: Use only screws with 4-40 UNC thread for fastening the connectors!

4.3.4 Power and sensor connection (± 15 VDC sensors) without opt. SPS module

[590 G / 590 H versions only]

4.3.4.1 Sensor power wiring via controller





Pins 4 and 8 must be bridged for operation. An optional switch would allow for motor interlock to prevent valve from moving.



- Use shielded sensor cable(s). Keep cable as short as possible, but locate it away from noise sources.
- Connect Power supply (+24 / GND and GND / -15V / +15V) at DB-9 male power connector and Sensors (+15V / -15V / 0V / + / -) at DB-15 female sensor connector exactly as shown in the drawing above!
- Connector: Use only screws with 4-40 UNC thread for fastening the connectors!

4.3.4.1 Sensor power wiring external



 Pins 4 and 8 must be bridged for operation. An optional switch would allow for motor interlock to prevent valve from moving.



- Use shielded sensor cable(s). Keep cable as short as possible, but locate it away from noise sources.
- Connect Power supply (+24 / GND and GND / -15V / +15V) at DB-9 male power connector and Sensors (0V / + / -) at DB-15 female sensor connector exactly as shown in the drawing above!
- Connector: Use only screws with 4-40 UNC thread for fastening the connectors!


4.3.5 Service port connection

The service port (connector: SERVICE) allows to connect the valve to a RS232 port of a computer. This requires a service cable and software from VAT. You can either use our freeware 'Control View', which can be downloaded from www.vatvalve.com or purchase our 'Control Performance Analyzer'. Alternatively the VAT Service Box2 can be connected to the service port for setup and local operation. The service port is not galvanic isolated. Therefore we recommend using this only for setup, testing and maintenance and not for permanent control. Refer also to chapter: «Local Operation» for details and to chapter «Spare parts / Accessories» for ordering numbers of service cable, software and Service Box 2.



Use only screws with 4–40 UNC thread for fastening the service port connector.

4.4 RS232 interface

NOTICE	
	<p>Wrong connection</p> <p>Wrong connection may result in damage of controller or power supply. Connect all cables exactly as shown in the following schematic.</p>

4.4.1 Settings

The factory default setting of the RS232 interface might be changed to fit the application by using the Control View software, the Control Performance Analyzer software or the Service Box 2. Refer to chapter: «RS232 Interface configuration».


4.4.2 RS232 Schematics

This interface allows for remote operation by means of a command set based on the RS232 protocol. In addition there are 2 digital inputs and 2 digital outputs. Digital inputs may be operated either by switches or by voltage sources.




Active digital inputs have higher priority than RS232 commands.

4.4.2.1 Configuration with switches for digital inputs



- Connect the RS232 interface connector exactly as shown in the drawing above!
- Use only screws with 4–40 UNC thread for fastening the DB-25 connector!

4.4.2.2 Configuration with voltage source for digital inputs



- Connect the RS232 interface connector exactly as shown in the drawing above!
- Use only screws with 4–40 UNC thread for fastening the DB-25 connector!

4.4.2.3 Digital inputs

Pin	Function	Signal type	Description	Priority
15	CLOSE VALVE	Digital input ¹⁾	<p>This function will close the valve. Valve will be in interlock mode as long as function is activated. After deactivation of function it will remain effective until</p> <ul style="list-style-type: none"> - OPEN valve digital input is active - converse RS232 control command have been received <p>The function is activated when optocoupler is 'on' in non inverted configuration. The function is activated when optocoupler is 'off' in inverted configuration.</p> <p>Configuration can be done in local operation via service port or in remote operation.</p>	1 ²⁾
17	OPEN VALVE	Digital input ¹⁾	<p>This function will open the valve. Valve will be in interlock mode as long as function is activated. After deactivation of function it will remain effective until converse RS232 control command have been received.</p> <p>The function is activated when optocoupler is 'on' in non inverted configuration. The function is activated when optocoupler is 'off' in inverted configuration.</p> <p>Configuration can be done in local operation via service port or in remote operation.</p>	2 ²⁾
23	DIGITAL GROUND	Digital ground	<p>Ground for all digital inputs. Ground is used when digital inputs are operated by switches. Connect switches to ground. See also to chapter: «Configuration with switches for digital inputs».</p>	
25	DIGITAL COMMON	Digital common	<p>Common for all digital inputs. Common is used when digital inputs are driven by voltage sources. Connect + or – terminal of source with common (optocoupler inputs are capable of bidirectional operation). See also chapter: «Configuration with voltage source for digital inputs».</p>	

¹⁾ All digital inputs are digitally filtered. Filter delay is 50ms. This means that digital signals must be applied for at least 50ms to be effective. Refer to chapter: «Schematics» for details about input circuit.

²⁾ Highest priority is 1. Functions with lower priorities will not be effective as long as higher priority functions are active. These digital inputs have higher priority than all RS232 commands. RS232 commands will not be accepted while digital inputs are active.

4.5 Initial operation

4.5.1 Setup procedure



To enable this valve for pressure control setup steps 1 to 6 must be performed. In case position control is required only it's sufficient to perform steps 1 to 4.

Setup step		Description
1	POWER UP	Turn on external + 24VDC power supply (and external ± 15 VDC for sensor power supply if required). Refer to chapter «Behavior during power up» for details.
2	INTERFACE CONFIGURATION	RS232 with analog output Baud rate, parity, data length and number of stop bits for valve must be selected. Refer to chapter «Interface configuration» for details.
3	VALVE CONFIGURATION	Basic configurations of the valve must be adapted according to application needs. Refer to chapter «Valve configuration» for details.
4	SENSOR CONFIGURATION	Basic configurations of the valve must be adapted according to application needs. Refer to chapter «Sensor configuration» for details.
5	ZERO	Compensation of the sensor offset voltage. Refer to chapter «ZERO» for details.
6	Fixed PI upstream configuration	Basic configurations of the valve must be adapted according to application needs. Refer to chapter «Fixed PI upstream configuration » for details.

4.5.2 RS232 Interface configuration

Interface configuration must be adapted according to application needs.

The factory default setting of the interface is shown in the table below.

Baud rate	Data bits	Stop bits	Parity	Digital input OPEN	Digital input CLOSE
9600	7	1	even	not inverted	not inverted

- Functionality of digital interlock inputs CLOSE VALVE and OPEN VALVE. These may be configured as 'not inverted', 'inverted' or 'disabled'. Default is 'not inverted'. Refer also to chapter «Digital inputs».
- Pressure and position range for RS232 communication must be selected. Default for pressure is 0 - 1'000'000. Default for position is 0 - 100'000.


Local operation: ('Control View', 'Control Performance Analyzer' or 'Service Box 2')	Remote operation: (Refer to chapter: «RS232 Setup commands» for details.)
Do configuration in menu 'Setup / Interface'.	1. Send INTERFACE CONFIGURATION
	2. Send RANGE CONFIGURATION

4.5.3 LOGIC I/O configuration

Default configuration for LOGIC I/O are:

#	Function	Mode	Input
Digital input	close valve	non inverted	enabled
#	Function	Mode	Output
Digital output	close	non inverted	enabled

The «LOGIC I/O» Digital input and Digital output can be adjusted.

Local operation: ('Control View', 'Control Performance Analyzer' or Hyper terminal)	Remote operation:
<p>Go to 'Tools / Terminal' menu and use the following commands.</p> <p>For Digital input: to change the configuration: [s:2601][abcdef][CR][LF] to read the configuration: [i:2601][CR][LF]</p> <p> Each element is separated with square brackets for clarity. Square brackets are not part of command syntax. All elements are ASCII characters. There are no spaces between the elements necessary. Command is <u>case sensitive</u>.</p> <p>data length 6 characters</p> <p>a 0 = close valve 1 = open valve</p> <p>b 0 = non inverted 1 = inverted</p> <p>c 0 = enabled 1 = disabled</p> <p>def 000 (reserved)</p> <p>For Digital output: to change the configuration: [s:2611][abcdef][CR][LF] to read the configuration: [i:2611][CR][LF]</p> <p>data length 6 characters</p> <p>a 0 = close 1 = open 2 = On</p> <p>b 0 = non inverted 1 = inverted</p> <p>c 0 = enabled 1 = disabled</p> <p>def 000 (reserved)</p> <p>For LOGIC I/O connector schematics see also chapter «LOGIC I/O».</p>	<p>It's not possible to configuration in remote operation.</p>

4.5.4 Valve configuration

Basic valve configuration must be adapted according to application needs.
 Definition of valve plate position in case of:

- **After power up**, default is 'close'.
- **Network failure**, for default settings refer to individual product data sheet.

Local operation: ('Control Performance Analyzer' or 'Service Box 2')	Remote operation: (Refer to chapter «Setup commands» for details)
With CPA: <ul style="list-style-type: none"> • Do valve configuration in menu 'Valve / Setup'. With SB2: <ul style="list-style-type: none"> • Do power up configuration in menu 'Setup / Valve'. • Do power fail configuration in menu 'Setup / Valve'. 	1. Send VALVE CONFIGURATION

4.5.5 Sensor configuration

Basic sensor configuration must be adapted according to application needs.

- ZERO function: This may be 'disabled' or 'enabled'. Default is 'enabled'. Refer also to chapter «ZERO».
- Sensor configuration with 1 sensor version [590 **G** -].

Local operation: ('Control Performance Analyzer' or 'Service Box 2')	Remote operation: (Refer to chapter «RS232setup commands» for details)
With CPA: <ol style="list-style-type: none"> 1. Do sensor configuration in menu 'Sensor / Setup'. With SB2: <ol style="list-style-type: none"> 2. Enable or disable ZERO function in menu 'Setup / Sensor'. 3. Do 1 sensor configuration in menu 'Setup / Sensor'. 	Send SENSOR CONFIGURATION ¹⁾

4.5.6 ZERO

ZERO allows for the compensation of the sensor offset voltage.

When ZERO is performed the current value at the sensor input is equated to pressure zero. In case of a 2 sensor system both sensor inputs will be adjusted. A max. offset voltage of +/- 1.4 V can be compensated. The offset value can be read via local and remote operation.

Local operation: (‘Control Performance Analyzer’ or ‘Service Box 2’)	Remote operation: (Refer to chapter «Control commands» resp. «Setup commands» for details)
With CPA: 4. Do the ZERO in menu ‘Sensor / Zero’.	1. Send OPEN VALVE
With SB2: 5. Go to menu ‘Zero / ZERO’ and follow instructions.	2. Wait until process chamber is evacuated and sensor signal is not shifting anymore.
	3. Send ZERO





- Do not perform ZERO as long as pressure gauge voltage is shifting otherwise incorrect pressure reading is the result. Refer to manual of sensor manufacturer for warm up time.
- Do not perform ZERO, if the base pressure of your vacuum system is higher than 1‰ of sensor full scale. We recommend disabling ZERO function in this case; refer to «Valve and sensor configuration» of the setup procedure. Otherwise incorrect pressure reading is the result.

4.5.7 Fixed PI upstream configuration



For easy setup (Local operation) of 'Pressure controller' and 'Pressure control parameter' please use the VAT "Control Performance Analyzer" CPA 3.0.

There is a free download on the VAT home page, refer to: <http://www.vatvalve.com/customer-service/informations-and-downloads/control-performance-analyzer>

<p align="center">Local operation: (‘Control Performance Analyzer’ 3.0)</p>	<p align="center">Remote operation:</p>
<ol style="list-style-type: none"> 1. Open the CPA 2. Click [Enter CPA] 3. Click [LOCAL] 4. Click [Setup] in menu ‘Pressure Control’ 1. Activate “fixed 1” (fixed PI upstream) and do the setup parameter adjustment according to application needs. (Default: P-Gain: 0.0056 / I-Gain: 0.0320) 	 <p>Refer to «Setup commands» > PRESSURE CONTROLLER CONFIGURATION.</p>


4.5.7.1 Position Limit open adjustment

Setup function	Command		Acknowledgement
	Description		
POSITION LIMIT OPEN	Set	a:101Aaaaaaa	a: 101A
	Get	a: 101A	a: 101Aaaaaaa
	data length 6 characters a Position Limit open 1...100'000 (Default is 100'000) This function does the «Position Limit open».		



Adjust the «Position Limit open» with Local operation. Refer the chapter: «Local operation» and follow the instructions.

- Open the CPA 3.0
- Click [LOCAL]
- Go to Tools / Terminal
- Enter (example) a:101A100000



4.6 Tuning of control performance

- Tuning of pressure control performance with PI control, refer to chapter: 4.7.2 Tuning of control performance with fixed PI pressure controller

4.6.1 Tuning of control performance with fixed PI pressure controller

4.6.1.1 Optimizing P gain and I gain

This valve may be used for downstream or upstream pressure control depending on configuration. The PI parameters of the pressure controller require correct adjustment. These parameters must be set once during system setup and are stored in the device memory which is power fail save. Based on the PI controller configuration, the valve is able to run fast and accurate pressure control cycles. The PI parameters can be evaluated using below instruction.



- In downstream control mode valve will move towards open when current pressure is higher than set point.
- In upstream control mode valve will move towards close when current pressure is higher than set point.

<p>Local operation: (‘Control Performance Analyzer’)</p>	<p>Remote operation: (Refer to chapter «Pressure control algorithm» > «Fixed 1 control algorithm » for details)</p>
<p>With CPA: Do the ‘fixed 1’ adjustment in menu ‘Pressure Control’ / ‘Setup’ / ‘fixed 1’. (Default: P-Gain: 0.0056 / I-Gain: 0.0320)</p>	<p>Send ‘Fixed 1 control algorithm parameter’.</p>

Introduction

PI controller mode is used if for any reason (e.g. too long system time constant) the adaptive control mode does not provide satisfying control performance.

In PI controller mode the parameters P gain and I gain have to be set according to the systems characteristics. The best set of parameters can be found by using the empiric method below.

1. Optimizing P gain and I gain.

1.1 Pressure and gas flow for optimization

A PI controller delivers the best results for a certain working point (pressure/gas flow). If there is only one working point, this pressure and gas flow has to be used for optimizing P and I gain. If there are several working points that have to be covered, the pressure for optimizing is the medium pressure between highest and lowest pressure to be controlled, the gas flow for optimizing is the highest flow out of all working points.

Two different pressure set points are necessary for optimization. Set point 1 (SP1) is the pressure for optimizing as determined above. Set point 2 (SP2) is about 10 - 20% lower than SP1.

Example: pressure range: 4 – 10 Torr
Flow range: 2 – 4 slm

Pressure set points and gas flow for optimization:

SP1 = 7 Torr
SP2 = 6 Torr
Gas flow = 4slm

1.2 Optimizing P gain


While optimizing P gain, the gas flow determined above has to be constant all the time.

Start optimization with P gain set to 1.0 and I gain set to 0.0.

Set chamber pressure to SP2, wait until the pressure is stable. Set pressure to SP1. If the transition from SP2 to SP1 results in a significant pressure over shoot or even does not stabilize at all, the P gain is too high. If there is no over shoot and the pressure reaches SP1 asymptotically and very slow, P gain is too low.

The optimal P gain value is found if the transition from SP2 to SP1 results in a slight pressure over shoot. It does not matter if there is still a deviation between SP1 and actual pressure.

Example:



1.3 Optimizing I gain


While optimizing I gain, the gas flow determined above has to be constant all the time.

Start with P gain set to half of the value found when optimizing P gain and set I gain to 1.0. Keep the P gain constant.

Set chamber pressure to SP2, wait until the pressure is stable. Set pressure to SP1. If the transition from SP2 to SP1 results in a significant pressure over shoot or if the valve position does not stabilize, I gain is too high. If the transition results in a slow asymptotical pressure rise and there is still a constant deviation to SP2, the I gain is too low.

The optimal value for I gain is found if the transition from SP2 to SP1 result in just a slight pressure over shoot, a stable valve position and the actual pressure matches SP2 exactly.

Example:



Check control performance over the whole control range with parameters above.

Required information for support:

- Go to 'Tools / Create Diagnostic File' in 'Control View' resp. 'Control Performance Analyzer' and save file
- Pressure / flow / gas conditions to be controlled
- Chamber volume
- Pumping speed (l/s) and pump type (e.g. turbo pump)
- System description
- Problem description

Send diagnostic file with and all required information to tuning-support@vat.ch

4.7 RS232 interface commands

4.7.1 RS232 command syntax

- Commands and values are case sensitive.
- Acknowledgement within 10ms after reception of command.
- Wait for acknowledgement before sending a new command.
- Command termination of each command is CR and LF.
CR = Carriage Return (0D hexadecimal), LF = Linefeed (0A hexadecimal)

4.7.2 Control commands

Control function	Command		Acknowledgement
	Description		
CLOSE VALVE	Set	C:	C:
	Valve will close.		
OPEN VALVE	Set	O:	O:
	Valve will open.		
HOLD	Set	H:	H:
	This function stops the valve at the current position. It is effective in PRESSURE CONTROL and POSITION CONTROL. The function can be revoked by a POSITION CONTROL, PRESSURE CONTROL, OPEN VALVE or CLOSE VALVE command.		
POSITION CONTROL	Set	R:aaaaaa	R:
	Get	i:38	i:38aaaaaaaa
	data length for Set 6 characters, for Get 8 characters aaaaaa position SETPOINT, value depends on configuration, refer to «RS232 setup commands, COMMUNICATION RANGE» for details Change to POSITION CONTROL mode and transfer of position SETPOINT value resp. reading of position SETPOINT. Remark: Reading returns position setpoint only in case pressure control is not selected.		
PRESSURE CONTROL	Set	S:aaaaaaaa	S:
	Get	i:38	i:38aaaaaaaa
	data length 8 characters aaaaaaaaa pressure SETPOINT, value depends on configuration, refer to «RS232 setup commands, COMMUNICATION RANGE» for details Change to PRESSURE CONTROL mode and transfer of pressure SETPOINT resp. reading of pressure SETPOINT. Remark: Reading returns pressure setpoint only in case pressure control is selected, otherwise position setpoint is returned.		

4.7.3 Inquiry commands

Inquiry function	Command		Acknowledgement
	Description		
POSITION	Get	A:	A:aaaaaa
	data length 6 characters aaaaaa position, return value depends on configuration, refer to «RS232 setup commands, COMMUNICATION RANGE» for details This function returns the current valve position. Remark: 999'999 is returned when the position is unknown, for example after power up during synchronization		
PRESSURE	Get	P:	P:saaaaaaa
	data length 8 characters s sign, 0 for positive readings, - for negative readings aaaaaaa pressure, return value depends on configuration, refer to «RS232 setup commands, COMMUNICATION RANGE» for details This function returns the actual pressure.		
SENSOR 1 OFFSET	Get	i:60	i:60aaaaaaaa
	data length 8 characters aaaaaaaa sensor 1 offset (-140000 ... 0140000 = -1.4V ... +1.4V) This function returns the sensor 1 offset voltage (adjusted by ZERO).		
SENSOR 2 OFFSET (not used)	Get	i:61	i:61aaaaaaaa
	data length: 8 characters aaaaaaaa sensor 2 offset (-140000 ... 0140000 = -1.4V ... +1.4V) This function returns the sensor 2 offset voltage (adjusted by ZERO).		
SENSOR 1 READING	Get	i:64	i:64saaaaaaa
	data length 8 characters s sign, 0 for positive readings, - for negative readings aaaaaaa sensor 1 reading, return value depends on configuration, refer to «RS232 setup commands, COMMUNICATION RANGE» for details This function returns direct reading from sensor 1 input.		
SENSOR 2 READING (not used)	Get	i:65	i:65saaaaaaa
	data length 8 characters s sign, 0 for positive readings, - for negative readings aaaaaaa sensor 2 reading, return value depends on configuration, refer to «RS232 setup commands, COMMUNICATION RANGE» for details This function returns direct reading from sensor 2 input.		

Inquiry function	Command		Acknowledgement
	Description		
DEVICE STATUS	Get	i:30	i:30 abcdefgh
	<p>data length 8 characters</p> <p>a Access Mode 0 = local operation 1 = remote operation 2 = locked remote operation</p> <p>b Control Mode 1 = synchronization 2 = POSITION CONTROL 3 = CLOSED 4 = OPEN 5 = PRESSURE CONTROL 6 = HOLD 7 = (reserved) 8 = INTERLOCK OPEN (by digital input) 9 = INTERLOCK CLOSED (by digital input) C = power failure D = safety mode E = fatal error (read «FATAL ERROR STATUS» for details)</p> <p>c Power Failure Option 0 = disabled 1 = enabled</p> <p>d Warning 0 = no warnings 1 = warnings (read «WARNINGS» and «ERROR STATUS» for details)</p> <p>efg Reserved</p> <p>h Simulation 0 = normal operation 1 = system simulation running</p> <p>This function returns status information about the valve. Remark: In simulation mode the valve can demonstrate pressure control capability independent of other equipment such as vacuum chamber, flow controller and gauge. Normal operation is not possible when simulation is running.</p>		
FATAL ERROR STATUS	Get	i:50	i:50 abc
	<p>data length 3 characters</p> <p>abc error code</p> <p>See in chapter «Trouble shooting» for details.</p> <p>This function returns an error code in case of any malfunction of the device.</p>		

Inquiry function	Command		Acknowledgement
	Description		
WARNINGS	Get	i:51	i:51 abcdefgh
	<p>data length 8 characters</p> <p>a 0 = no service required 1 = service request, it is indicated when the control unit detects that motor steps are apparently not effective. This may happen when the valve is heavily contaminated or the gate seal is heavily sticking. These 'lost' steps are recognized and will be repeated to attempt target position in the short term. But in the medium term the valve requires cleaning or inspection.</p> <p>b 0 = LEARN (not used) data set present, 1 = LEARN (not used) data set not present</p> <p>c 0 = power failure battery ready 1 = power failure battery not ready</p> <p>d 0 = compressed air supply ok 1 = compressed air supply not ok</p> <p>efgh reserved, do not use</p> <p>This function returns warning information about the valve. If a warning is present countermeasure should be taken. Use RESET command to delete service request bit. Remark: Without LEARN (not used) the valve is not able to run pressure control</p>		
THROTTLE CYCLE COUNTER	Get	i:70	i:70 aaaaaaaaaa
	<p>data length 10 characters</p> <p>aaa...aaa number of throttle cycles</p> <p>This function returns the number of throttle cycles. A movement from max. throttle position to open back to max. throttle position counts as one cycle. Partial movements will be added up until equivalent movement is achieved.</p>		
ISOLATION CYCLE COUNTER	Get	i:71	i:71 aaaaaaaaaa
	<p>data length 10 characters</p> <p>aaa...aaa number of isolation cycles</p> <p>This function returns the number of isolation cycles. Each closing of the sealing ring counts as one cycle.</p>		
POWER UP COUNTER	Get	i:72	i:72 aaaaaaaaaa
	<p>data length 10 characters</p> <p>aaa...aaa number of power ups</p> <p>This function returns the number of control unit power ups.</p>		

Inquiry function	Command		Acknowledgement
	Description		
ASSEMBLY	Get	i:76	i:76 xxxxxxsyyyyyyabc
	data length xxxxxx s yyyyyy a b c	17 characters position, return value depends on configuration, refer to «RS232 setup commands, COMMUNICATION RANGE» for details sign, 0 for positive pressure readings, - for negative pressure readings pressure, return value depends on configuration, refer to «RS232 setup commands, COMMUNICATION RANGE» for details 0 = local operation 1 = remote operation 2 = locked remote operation 0 = Initialization (refer to chapter: «Behavior during power up») 1 = synchronization 2 = POSITION CONTROL 3 = CLOSE 4 = OPEN 5 = PRESSURE CONTROL 6 = HOLD 7 = LEARN (not used) 8 = INTERLOCK OPEN (by digital input) 9 = INTERLOCK CLOSE (by digital input) C = power failure D = safety mode E = fatal error (read «FATAL ERROR STATUS» for details) 0 = no warning 1 = warning present (read «WARNINGS» and «ERROR STATUS» for details)	
This function returns an assembly consisting of POSITION, PRESSURE and main status information for the valve.			
HARDWARE CONFIGURATION	Get	i:80	i:80 abcdefgh
	data length a b c d efgh	8 characters 0 = Power Failure Option (PFO) not equipped 1 = Power Failure Option (PFO) equipped 0 = ±15V sensor power supply (SPS) not equipped 1 = ±15V sensor power supply (SPS) equipped 2 = RS232 Interface without analog outputs 3 = RS232 Interface with analog outputs 1 = 1 sensor version, 2 = 2 sensor version reserved, do not use	
This function returns the hardware configuration of the device.			
FIRMWARE CONFIGURATION	Get	i:82	i:82 aaaaaaaa
	data length aaaaaaaa	8 characters firmware version, e.g. 600P1G0002	
This function returns firmware version of the device.			
IDENTIFICATION	Get	i:83	i:83 aaaaaaaaaaaaaaaaaaaa
	data length aaa...aaa	20 characters identification code, e.g. 59024-GEAG-0001/0001/, unused digits are filled up with spaces (20 hexadecimal)	
This function returns an identification code. This code is unique for each valve and allows tracing.			

Inquiry function	Command		Acknowledgement
	Description		
FIRMWARE NUMBER	Get	i:84	i:84aaaaaa
	data length 20 characters aaaaaa Firmware number e.g. 769650 This function returns the VAT Firmware number.		


4.7.4 Position Limit open (setup command)

Setup function	Command		Acknowledgement
	Description		
POSITION LIMIT OPEN	Set	a:101Aaaaaaa	a: 101A
	Get	a: 101A	a: 101Aaaaaaa
	data length 6 characters a Position Limit open 1...100'000 (Default is 100'000) This function does the «Position Limit open».		



It is also possible to do «Position Limit open» with Local operation. Refer the chapter: «Local operation» and follow the instructions.

- Open the CPA 4.0
- LOCAL
- Tools / Terminal



Example

4.7.5 Setup commands

Setup function	Command		Acknowledgement																								
	Description																										
ACCESS MODE	Set	c:01aa	c:01																								
	<p>data length: 2 characters aa 00 = local operation (service port) 01 = remote operation, change to local enabled 02 = locked remote operation, change to local not possible via service port</p> <p>This function selects the access authorization to the valve. To read access mode use inquiry command DEVICE STATUS. Remark: If ACCESS MODE is local operation and communication to service port is interrupted the valve will automatically change to remote operation.</p>																										
VALVE CONFIGURATION	Set	s:04abcdefgh	s:04																								
	Get	i:04	i:04abcdefgh																								
<p>data length 8 characters</p> <table border="0"> <tr> <td>a</td> <td>Valve position after power up</td> <td>0 = close 1 = open</td> </tr> <tr> <td>b</td> <td>Valve position after power failure</td> <td>0 = close 1 = open</td> </tr> <tr> <td>c</td> <td>External isolation valve function</td> <td>0 = no 1 = yes</td> </tr> <tr> <td>d</td> <td>Control stroke limitation</td> <td>0 = no 1 = yes</td> </tr> <tr> <td>e</td> <td>Network failure end position</td> <td>0 = valve will close 1 = valve will open 2 = valve stay on actual position</td> </tr> <tr> <td>f</td> <td>Slave offline position</td> <td>0 = valve will close 1 = valve will open 2 = valve stay on actual position</td> </tr> <tr> <td>g</td> <td>Synchronization start</td> <td>0 = standard 1 = special command 2 = open command 3 = all move commands 4 = always</td> </tr> <tr> <td>h</td> <td>Synchronization mode</td> <td>0 = short 1 = full</td> </tr> </table> <p>This function does the valve configuration.</p>				a	Valve position after power up	0 = close 1 = open	b	Valve position after power failure	0 = close 1 = open	c	External isolation valve function	0 = no 1 = yes	d	Control stroke limitation	0 = no 1 = yes	e	Network failure end position	0 = valve will close 1 = valve will open 2 = valve stay on actual position	f	Slave offline position	0 = valve will close 1 = valve will open 2 = valve stay on actual position	g	Synchronization start	0 = standard 1 = special command 2 = open command 3 = all move commands 4 = always	h	Synchronization mode	0 = short 1 = full
a	Valve position after power up	0 = close 1 = open																									
b	Valve position after power failure	0 = close 1 = open																									
c	External isolation valve function	0 = no 1 = yes																									
d	Control stroke limitation	0 = no 1 = yes																									
e	Network failure end position	0 = valve will close 1 = valve will open 2 = valve stay on actual position																									
f	Slave offline position	0 = valve will close 1 = valve will open 2 = valve stay on actual position																									
g	Synchronization start	0 = standard 1 = special command 2 = open command 3 = all move commands 4 = always																									
h	Synchronization mode	0 = short 1 = full																									

Setup function	Command		Acknowledgement
	Description		
SENSOR SCALE	Set	s:05 aaaaabcd	s:05
	Get	i:05	i:05 aaaaabcd
	data length 8 characters a Value 00001...99999 (10000 = 1.0000) b Sign Exponent 0 = “-”, 1 = “+” c Exponent 0...4 d Pressure Unit 0 = Pa 1 = bar 2 = mbar 3 = ubar 4 = Torr 5 = mTorr 6 = atm 7 = psi 8 = psf Example: 10000114 = 10Torr (input from high range sensor)		
SENSOR 1 LINEARIZATION	Set	s:17 aaaabbbb	s:17
	Get	i:17	i:17 aaaabbbb
	data length 8 characters a logarithmic resolution[millivolt /decade] 0000 = linearizing off 0001 = min. value 9999 = max. value (default value: 0000 = linearizing off) b full scale [millivolt] 0001 = min. value 9999 = max. value (default value in logarithmic mode: 5324 = 5.324V) (becomes linear full scale = 1000000) Pressure control algorithm adaptive downstream needs a linear sensor signal, therefore a logarithmic signal must be linearized. Example: s:1700000000 = Linear sensor Example: s:1810007800 = Logarithmic sensor (1.0V/decade, Linear full scale at 7.8V)		

Setup function	Command		Acknowledgement
	Description		
SENSOR 2 LINEARIZATION (not used)	Set	s:18 aaaabbbb	s:18
	Get	i:18	i:18 aaaabbbb
	data length 8 characters a logarithmic resolution[millivolt /decade] 0000 = linearizing off 0001 = min. value 9999 = max. value (default value: 0000 = linearizing off) b full scale [millivolt] 0001 = min. value 9999 = max. value (default value in logarithmic mode: 5324 = 5.324V) (becomes linear full scale = 1000000) Pressure control algorithm adaptive downstream needs a linear sensor signal, therefore a logarithmic signal must be linearized. Example: s:1700000000 = Linear sensor Example: s:1810007800 = Logarithmic sensor (1.0V/decade, Linear full scale at 7.8V)		
SENSOR AVERAGE	Set	s:19 abbbbbbb	s:19
	Get	i:19	i:19 abbbbbbb
	data length 8 characters a Average time 0 = 0.0 sec 1 = 0.1 sec 2 = 0.2 sec 3 = 0.3 sec 4 = 0.4 sec 5 = 0.5 sec 6 = 0.6 sec 7 = 0.7 sec 8 = 0.8 sec 9 = 0.9 sec A = 1.0 sec b Reserved set to 0000000 Remark: For pressure control averaging of sensor signal is not recommended. This function does the sensor average configuration.		

Setup function	Command		Acknowledgement
	Description		
COMMUNICATION RANGE CONFIGURATION	Set	s:21abcdefgh	s:21
	Get	i:21	i:21abcdefgh
	<p>data length 8 characters a range for POSITION: 0 = 0 – 1'000, 1 = 0 – 10'000, 2 = 0 – 100'000 bcdefgh upper value for PRESSURE and SENSOR READING: 1000 ... 1000000 e.g. 0010000 -> pressure range 0 – 10'000</p> <p>This function defines the communication range between the valve and the host computer for POSITION, PRESSURE and SENSOR READING. Remark: In case ZERO has been performed, gauge offset for PRESSURE and SENSOR READING is compensated. Remark: In case 2 sensor operation for pressure control is selected, PRESSURE covers high range gauge because switchover between sensors is done automatically. SENSOR 1 READING and SENSOR 2 READING always return full scale values according to selected range.</p>		

Setup function	Command		Acknowledgement)	
	Description			
INTERFACE CONFIGURATION	Set	s:20 abcdefgh	s:20	
	Get	i:20	i:20 abcdefgh	
	data length 8 characters a baud rate: 0 = 600 1 = 1200k 2 = 2400 3 = 4800 4 = 9600 5 = 19.2k 6 = 38.4k 7 = 57.6k 8 = 115.2k b parity bit: 0 = even 1 = odd 2 = mark 3 = space 4 = no c data length: 0 = 7 bit 1 = 8 bit d number of stop bits: 0 = 1 1 = 2 e 0 (reserved, do not change) f digital input OPEN VALVE: 0 = not inverted 1 = inverted 2 = disabled g digital input CLOSE VALVE: 0 = not inverted 1 = inverted 2 = disabled h 0 (reserved, do not change)			
	This function does the RS232 and digital input configuration. Remark: Digital outputs are always enabled.			
	ZERO	Set	Z:	Z:
		This command initiates ZERO to compensate for offset of gauge(s). Remark: Refer to «ZERO» for correct zero procedure.		
	PRESSURE ALIGNMENT	Set	c:6002 aaaaaaaa	c:60
		data length: 8 characters aaaaaaaaa System base pressure, value depends on configuration, refer to «RS232 setup commands, COMMUNICATION RANGE» for details. Alignment range is equivalent to max. +/-1.4V sensor signal. This command aligns PRESSURE to a certain value. Also SENSOR READING will be aligned accordingly. It might be used instead of ZERO in case base pressure is not low enough.		

Setup function	Command		Acknowledgement
	Description		
VALVE SPEED	Set	V:00aaaa	V:
	Get	i:68	i:680000aaaa
	data length 6 characters starting with double zero for writing 8 characters starting with quadruple zero for reading aaaa valve speed, 1 ... 1000 (1 = min. speed, 1000 = max. speed) This command allows changing the actuating speed of the valve plate. Speed selection is effective for pressure control and position control. Open valve and close valve are always done with max. speed. Remark: Refer to «Valve speed adjustment» for details.		
RESET	Set	c:82aa	c:82
	data length 2 characters aa 00 = reset service request bit from WARNINGS 01 = reset FATAL ERROR (restart control unit) This function resets warnings and errors.		
PRESSURE CONTROLLER	Set	s:02Z0a select pressure controller as active pressure controller	s:02
	Get	i:02Z00 get active pressure controller	i:02Z00a
	This command selects the pressure controller mode. a Pressure controller: 0 = Adaptive downstream 1 = Fixed 1 (PI) upstream (default) 2 = Fixed 2 (PI) (downstream or upstream) 3 = Soft pump Examples: <ul style="list-style-type: none"> To set the soft pump pressure controller as active pressure controller, send s:02Z003 If the answer of the command i:02Z00 is i:02Z002, the fixed 2 pressure controller is active. 		

Setup function	Command		Acknowledgement
	Description		
PRESSURE CONTROLLER CONFIGURATION	Set	s:02abbc configure parameter: set parameter bb of pressure controller a to value c	s:02
	Get	i:02abb get value c of parameter bb of pressure controller a	i:02abbc
	<p>a Pressure controller: A = Adaptive downstream pressure controller B = Fixed 1 pressure controller (downstream or upstream) C = Fixed 2 pressure controller (downstream or upstream) D = Soft pump pressure controller</p> <p>bb Parameter number (see table below)</p> <p>c Parameter value, depends on parameter number a floating-point type or a integral type value, max length = 20 characters</p> <p>floating-point type format: x.y or x Maximum length of expression: 12 Examples: 3455.1505, 21154.0 or 318</p> <p>integer type format: x Maximum length of expression: 12 Examples: 9785, 4565, 1</p> <p>For details (commands etc.), see the next tables.</p>		

4.7.5.1 Overview pressure controller

Parameter	Parameter number (bb)	Pressure controller (a)			
		A Adaptive	B Fixed 1	C Fixed 2	D Soft pump
SENSOR DELAY	00	✓	–	–	–
RAMP TIME	01	✓	✓	✓	✓
RAMP MODE	02	✓	✓	✓	✓
CONTROL DIRECTION	03	–	✓	✓	–
P-GAIN (for A = GAIN FACTOR)	04	✓	✓	✓	✓
I-GAIN	05	–	✓	✓	–

✓ Existent for this pressure controller / – Not used for this pressure controller

Command examples:

Set GAIN FACTOR of the adaptive pressure controller to the value 1.075	s:02A041.075
GET GAIN FACTOR of adaptive pressure controller	i:02A04 → Answer is i:02A041.075 → Value = 1.075
Set RAMP TIME of soft pump pressure controller to the value 281 seconds	s:02D01281
Get RAMP TIME of soft pump pressure controller	i:02D01 → Answer is i:02D01281 → Value = 281

4.7.6 Pressure control algorithm

4.7.6.1 Adaptive control algorithm (downstream)

Parameter	Command		Request	Data Type	Values
SENSOR DELAY	Set	s:02A00c	s:02	FLOAT	c = 0.00...1.00 Default is: 0.00 s
	Get	i:02A00	i:02A00c		
RAMP TIME	Set	s:02A01c	s:02	FLOAT	c = 0.00...1'000'000.0 Default is: 0.00 s
	Get	i:02A01	i:02A01c		
RAMP MODE	Set	s:02A02c	s:02	UINT	c = 0 or 1 0 = constant time 1 = constant slope Default is: 0
	Get	i:02A02	i:02A02c		
GAIN FACTOR	Set	s:02A04c	s:02	FLOAT	c = 0.0001...7.5 Default is: 1.0
	Get	i:02A04	i:02A04c		

Explanation:

SENSOR DELAY

Sensor response time [s]

The SENSOR DELAY is a control parameter to compensate delays during the pressure detection. Pipes and orifices for sensor attachment can cause delays in response time and could impact badly the pressure control stability. By adapting this parameter to the approximate delay time stability problems can be reduced. But control response time will be slowed down by this measure.

RAMP TIME

Pressure setpoint ramp time [s]

RAMP MODE

Mode = 0 Constant Time	The RAMP TIME is dependent on the adjusted parameter ramp time and is always the same independent of the control deviation. That means the ramp time from the actual value to the setpoint value is the adjusted parameter ramp time value.
Mode = 1 Constant Slope	The RAMP TIME is dependent on the adjusted parameter ramp time and is different depending on the control deviation. The RAMP TIME is calculated corresponding to the sensor full scale value (10V). Ramp time = 10 sec.; ramp time slope is SFS (10V) in 10 Seconds.

In the adaptive pressure controller mode, the RAMP TIME parameter also can be a value to minimize over- / undershooting. The ramp could be used to harmonize the adaptive control algorithm.

GAIN FACTOR

The GAIN FACOTR is a control parameter to adapt the performance of the pressure control algorithm. A higher gain results in faster response, higher over- / undershoot of pressure. A lower gain results in slower response, lower over- / undershoot of pressure.

Example:

Set SENSOR DELAY of the adaptive pressure controller to the value 0.75

Command	Pressure controller	Parameter selection variable	Parameter value (seconds)
s:02	A (a)	00 (bb)	0.75 (c)

→ s:02A000.75



To optimize adaptive control algorithm, refer to chapter «Tuning of control performance».

4.7.6.2 Fixed 1 control algorithm (default fixed PI upstream)

Parameter	Command		Request	Data Type	Values
RAMP TIME	Set	s:02B01c	s:02	FLOAT	c = 0.00...1'000'000.0 Default is: 0.00
	Get	i:02B01	i:02B01c		
RAMP MODE	Set	s:02B02c	s:02	UINT	c = 0 or 1 0 = constant time 1 = constant slope Default is: 0
	Get	i:02B02	i:02B02c		
CONTROL DIRECTION	Set	s:02B03c	s:02	UINT	c = 0 or 1 0 = downstream 1 = upstream Default is: 0
	Get	i:02B03	i:02B03c		
P-GAIN	Set	s:02B04c	s:02	FLOAT	c = 0.001...100 Default is: 0.0056
	Get	i:02B04	i:02B04c		
I-GAIN	Set	s:02B05c	s:02	FLOAT	c = 0...100.0 Default is: 0.0320
	Get	i:02B05	i:02B05c		

Explanation:

RAMP TIME

Pressure setpoint ramp time [s]

RAMP MODE

Mode = 0 Constant Time	The RAMP TIME is dependent on the adjusted parameter ramp time and is always the same independent of the control deviation. That means the ramp time from the actual value to the setpoint value is the adjusted parameter ramp time value.
Mode = 1 Constant Slope	The RAMP TIME is dependent on the adjusted parameter ramp time and is different depending on the control deviation. The RAMP TIME is calculated corresponding to the sensor full scale value (10V). Ramp time = 10 sec.; ramp time slope is SFS (10V) in 10 Seconds.

CONTROL DIRECTION

The CONTROL DIRECTION defines the type of application, if the valve is mounted in downstream or upstream. Downstream means the valve is after the chamber and before the pump. Upstream, valve is mounted before chamber and pump.

P-GAIN / I-GAIN

The P-GAIN is the proportional factor of the fixed control algorithm. The I-GAIN is the integral factor.

Example:

Set RAMP MODE of the Fixed 1 pressure controller to the value 0 (fixed time)

Command	Pressure controller	Parameter selection variable	Parameter value
s:02	B (a)	02 (bb)	0 (c)

→ s:02B020



To optimize Fixed 1 control algorithm, refer to chapter «Tuning of control performance».

4.7.6.3

Fixed 2 control algorithm

Parameter	Command	Request	Data Type	Values	
RAMP TIME Pressure setpoint ramp time [s]	Set	s:02C01 c	s:02	FLOAT	c = 0.00...1'000'000.0 Default is: 0.00
	Get	i:02C01			
RAMP MODE	Set	s:02C02 c	s:02	UINT	c = 0 or 1 0 = constant time 1 = constant slope Default is: 0
	Get	i:02C02			
CONTROL DIRECTION	Set	s:02C03 c	s:02	UINT	c = 0 or 1 0 = downstream 1 = upstream Default is: 0
	Get	i:02C03			
P-GAIN	Set	s:02C04 c	s:02	FLOAT	c = 0.001...100 Default is: 0.1
	Get	i:02C04			
I-GAIN	Set	s:02C05 c	s:02	FLOAT	c = 0...100.0 Default is: 0.1
	Get	i:02C05			

Explanation: Refer to: «Fixed 1 control algorithm»

4.7.6.4 Soft pump control algorithm

Parameter	Command	Request	Data Type	Values
RAMP TIME	Set	s:02D01c	s:02	FLOAT c = 0.00...1'000'000.0 Default is: 0.00
	Get	i:02D01	i:02D01c	
RAMP MODE	Set	s:02D02c	s:02	UINT c = 0...1 0 = constant time 1 = constant slope Default is: 0
	Get	i:02D02	i:02D02c	
P-GAIN	Set	s:02D04c	s:02	FLOAT c = 0.001...100 Default is: 0.1
	Get	i:02D04	i:02D04c	

Explanation:

RAMP TIME

Pressure setpoint ramp time [s]

RAMP MODE

Mode = 0 Constant Time	The RAMP TIME is dependent on the adjusted parameter ramp time and is always the same independent of the control deviation. That means the ramp time from the actual value to the setpoint value is the adjusted parameter ramp time value.
Mode = 1 Constant Slope	The RAMP TIME is dependent on the adjusted parameter ramp time and is different depending on the control deviation. The RAMP TIME is calculated corresponding to the sensor full scale value (10V). Ramp time = 10 sec ; ramp time slope is SFS (10V) in 10 Seconds.

P-GAIN

The P-GAIN is the proportional factor of the fixed control algorithm.







To optimize soft pump control algorithm, refer to chapter «Tuning of control performance».

4.7.7 Error messages

Description	Error message
Protocol	
Parity error	E:000001
Input buffer overflow (to many characters)	E:000002
Framing error (data length, number of stop bits)	E:000003
Overrun (Service interface: Input buffer register overflow)	E:000004
Commands	
<CR> or <LF> missing	E:000010
: missing	E:000011
Invalid number of characters (between : and)	E:000012
Invalid value	E:000023
Value out of range	E:000030
Hardware	
Command not applicable for hardware configuration	E:000041
Setup	
ZERO disabled	E:000060
Device Status	
Command not accepted due to local operation	E:000080
Command not accepted, Service Interface locked	E:000081
Command not accepted due to synchronization, CLOSED or OPEN by digital input, safety mode or fatal error	E:000082
Not accepted calibration and test mode	E:000089

5 Operation

	 WARNING
	<p>Unqualified personnel Inappropriate handling may cause serious injury or property damage. Only qualified personnel are allowed to carry out the described work.</p>

	 CAUTION
	<p>Valve opening Human body parts may get jammed or easily injured. Do not operate before valve is installed completely in the vacuum system.</p>

5.1 Normal operation

This valve is designed for upstream pressure control in vacuum chambers. It can be employed in a pressure control mode or a position control mode. In both cases local or remote operation is possible.

5.1.1 Local operation

Local operation means that the valve is operated via the service port using a computer or the Service Box 2. When using a computer, a service cable and a software from VAT are required. You can either download our freeware 'Control View' from www.vatvalve.com or purchase our 'Control Performance Analyzer'. This software are beneficial especially for setup, testing and maintenance.

How to start: Connect service cable, start software and push button 'LOCAL' to enable for operation. Then enter menu 'Setup / Sensor' and do sensor configuration according to your application to make sure that you get the correct pressure displayed.

'Control view' supports:

- parameter setup
- manual control
- numeric monitoring
- basic diagnostic

'Control Performance Analyzer' supports:

- parameter setup
- manual control
- sequence control
- numeric and graphical monitoring
- data recording
- data analysis
- advanced diagnostic




Figure 5-1



When communication to service port is interrupted the valve will change to remote operation. So when service cable will be disconnected or software will be shut down, the valve returns automatically to remote operation. This may result in an immediate movement of the valve depending on remote control.

Refer to chapter: «Accessories» for ordering numbers of service cable, software and Service Box 2.

5.1.2 Remote operation

This product is equipped with an RS232 interface to allow for remote operation. See section «RS232 Interface» for details. 'Control View' software, 'Control Performance Analyzer' software or 'Service Box 2' may be used for monitoring during remote control.



In case 'Control View' or 'Control Performance Analyzer' software is connected to valve make sure 'REMOTE' button is pushed to enable for remote operation. In case Service Box 2 is connected to valve make sure the LED on button 'LOCAL' is OFF for remote operation.

5.2 Close valve

The valve is completely closed when the stop is reached. A stopper is implemented in the leak valve to prevent over tightening of the seat in the closed position.

Local operation: ('Control View', 'Control Performance Analyzer' or 'Service Box 2')	Remote operation: (Refer to chapter: «control commands» for details.)
Push CLOSE button	Send CLOSE VALVE

5.3 Open valve

The valve is completely open when the mechanical stop is reached.

Local operation: ('Control View', 'Control Performance Analyzer' or 'Service Box 2')	Remote operation: (Refer to chapter: «control commands» for details.)
Push OPEN button	Send OPEN VALVE

5.4 Position control

The valve position is directly controlled according to the position setpoint.

Local operation: (‘Control View’, ‘Control Performance Analyzer’ or ‘Service Box 2’)	Remote operation: (Refer to chapter: «control commands» for details.)
Select or enter position setpoint	Send POSITION CONTROL



Operating in position control mode can be done very easily. When setting a defined position by opening the valve, a pressure in the chamber will be achieved dependent on application specific parameters. This pressure will be slightly higher than the same defined position set by closing the valve. It is therefore recommended that this difference is evaluated prior to operating in position control.

5.5 Pressure control




- To prepare valve for PRESSURE CONTROL perform complete chapter «Setup procedure».
- The valve has parameters that may be modified to tune pressure control performance. Refer to chapter: «Tuning of control performance».

Operating in position control mode can be done very easily. When setting a defined position by opening the valve, a pressure in the chamber will be achieved dependent on application specific parameters. This pressure will be slightly higher than the same defined position set by closing the valve. It is therefore recommended that this difference is evaluated prior to operating in position control.

Local operation: (‘Control View’, ‘Control Performance Analyzer’ or ‘Service Box 2’)	Remote operation: (Refer to chapter: «control commands» for details.)
Select or enter pressure setpoint	Send PRESSURE CONTROL

5.6 Display information

There is a 4 digit display located on the panel. It displays configuration, status and position information. For details refer to following tables.



5.6.1 Power up

Description	Digit 1	Digit 2	Digit 3	Digit 4
<ul style="list-style-type: none"> Power On: All dots are illuminated 	#	#	#	#
<ul style="list-style-type: none"> 1st information for about 3s: Firmware generation [e.g. 1G..] 	1	G		
<ul style="list-style-type: none"> 2st information for about 3s: Firmware version and firmware revision [e.g. 21 00] 	2	1	0	0
<ul style="list-style-type: none"> 3rd information for about 3s: Valve type [e.g. 590] 		5	9	0
<ul style="list-style-type: none"> 4nd information for about 3s: Controller configuration In case D999 is displayed, motor interlock is active. Refer to «Safety mode» for details. 		2 = RS232 interface	0 = basic	1 = 1 sensor version
SYNC indicates that powerup synchronization is running.	S	Y	N	C

5.6.2 Operation

Description / Mode	Digit 1	Digit 2	Digit 3	Digit 4
PRESSURE CONTROL mode	P	0 . . . 100 = valve position (% , 0 = closed / 100 = open)		
POSITION CONTROL mode	V			
Valve closed	C			
Valve open	O			
Closed / open interlock (Valve closed / open by digital input)	I			
HOLD (position frozen) activated	H			
Safety mode established. Refer to chapter «Safety mode» for details.	D			
Power failure	F			



RxD / TxD activity of RS232 communication is displayed by 2 blinking dots in digit 2. The lower dot indicates RxD activity where the upper dot indicates TxD activity. The indication is not real time.

5.6.3 Errors

Description	Digit 1	Digit 2	Digit 3	Digit 4
Fatal error occurred	E	Error code. Refer to chapter: «Trouble shooting» for details.		

5.6.4 Safety mode

By means of an external switch (see connection diagrams chapter «Electrical connection») the motor power supply can be interrupted. In this case the valve enters the 'safety mode'. This motor interlock prevents the valve from moving (e.g. maintenance work). Data reading from the control unit remains possible.

When motor interlock is active during power up the valve directly enters the 'safety mode' and is not able to synchronize. Display shows 'D C' or 'D999'. In this case synchronization cycle will be done when motor interlock is deactivated. Then Display shows 'INIT' for a moment followed by 'SYNC'.

When 'safety mode' is entered from operation (i.e. pressure control mode), the unit will automatically switch to position control mode and remain at current position. Once motor interlock is deactivated the unit remains in position control mode.

5.7 Operation under increased temperature

	CAUTION
	<p>Hot valve</p> <p>Heated valve may result in minor or moderate injury. Do not touch valve during operation. Wait until the valve is cooled down complete before doing any work.</p>

This valve may be operated in the temperature range mentioned in chapter «Technical data».

	NOTICE
	<p>Temperature differences</p> <p>Temperature differences they may affect the performance of the valve. Temperature differences exceeding 30°C throughout the valve are not allowed. Ideally the valve do not get actuated until the temperature is levelled throughout the valve.</p>

5.7.1 Bake-out

Bake out temperature	Beak-out area
<ul style="list-style-type: none"> • Open / Close: ≤ 300°C • Actuator: ≤ 50°C 	

5.8 Behavior during power up

Valve position before power up:	Reaction of valve:
	Valve power up configuration = closed (default)
Closed (isolated)	Valve remains closed. Display shows 'C C'.
All other than closed (not isolated)	Valve position after power up is closed

Refer also to chapter «Display information».

5.9 Behavior during power failure

Valve position before power failure:	Reaction of valve:
Any	Valve remains at current position.

All parameters are stored in a power fail save memory.

5.10 Trouble shooting

Failure	Check	Action
- No dots lighted on display	- 24 V power supply ok?	- Connect valve to power supply according to chapter «Electrical connection» and make sure that power supply is working.
- Remote operation does not work	- Local operation via service port active	- Switch to remote operation.
	- Safety mode active, check for D on display?	- Provide power to motor to allow for operation. - Refer to chapter «Electrical connection» for details.
- Display shows «E 20» and position is 009999 - (fatal error - limit stop of valve unit not detected)	- Clamp coupling screw not fastened?	- Tighten screw. Refer to chapter «Tightening torque» for details. RESET or restart of valve is necessary.
- Display shows «E 22» and position is 009999 - (fatal error - rotation angle of valve plate limited during operation)	- Valve unit heavy contaminated? - Valve plate mechanically obstructed?	- Clean valve unit according to chapter «Maintenance procedure». - Resolve obstruction. - Reset control unit. Cycle power (OFF→ON). or - Send reset command: - local via service port with CV/CPA/Service Box2.
- Display shows «E 40» and position is 009999 - (fatal error - motor driver failure detected)		- Replace control and actuating unit according to chapter «Maintenance procedures».
- Display shows «D 0» - Motor Interlock is open	- Motor power supplied?	- Provide power to motor to allow for operation. - Refer to chapter «Electrical connection» for details.
- CLOSE VALVE does not work	- Safety mode active, check for D on display? - Maintenance mode active	- Provide power to motor to allow for operation. - Refer to chapter «Electrical connection» for details. - Refer to "Display shows «M C»" in this table
- OPEN VALVE does not work	- Safety mode active, check for D on display? - Maintenance mode active	- Provide power to motor to allow for operation. - Refer to chapter «Electrical connection» for details. - Refer to "Display shows «M100»" in this table
- Display shows «M C» - Maintenance mode active		- Pin 14 of service connector is connected to ground. Plate will close. Further movement of plate is blocked. ¹⁾
- Display shows «M100» - Maintenance mode active		- Pin 13 of service connector is connected to ground. Plate will open. Further movement of plate is blocked. ¹⁾

¹⁾ Priority of pin 14 is higher than pin 13. If pin 14 is connected to ground after pin 13 the valve will close. Ground of service connector is at pin 4 and 8.

Failure	Check	Action
<ul style="list-style-type: none"> - Pressure reading is wrong or - pressure reading is negative 	<ul style="list-style-type: none"> - Sensor(s) connected? - Does sensor power supply provide enough power for sensor(s)? 	<ul style="list-style-type: none"> - Refer to chapter «Electrical connection». - Check valve version on page 1. Verify configuration. Refer to chapter «Setup procedure». - Verify sensor supply voltage.
<ul style="list-style-type: none"> - PRESSURE CONTROL does not work 	<ul style="list-style-type: none"> - Safety mode active, check for D on display? - PRESSURE CONTROL selected, check for P on display? - Fixed PI done? 	<ul style="list-style-type: none"> - Provide power to motor to allow for operation. - Refer to chapter «Electrical connection» for details. - Select PRESSURE CONTROL mode. - Refer to chapter «Pressure control» for details. - Perform Fixed PI. - Refer to chapter «Setup procedure» for details.
<ul style="list-style-type: none"> - PRESSURE CONTROL not optimal 	<ul style="list-style-type: none"> - Setup done completely? - Fixed PI done? - Fixed PI interrupted? - Optimizing fixed PI done? - Is sensor range suited for application? - Noise on sensor signal? 	<ul style="list-style-type: none"> - Perform «Setup procedure» completely. - Perform Fixed PI. - Repeat Fixed PI. - Repeat Fixed PI with stable gas flow. - Optimizing fixed PI for application. - Refer to «Optimize P-Gain, I-Gain » for details. - Use a sensor with suitable range (controlled pressure should be >3% and < 98% of sensor full scale). - Make sure a shielded sensor cable is used.



If you need any further information, please contact one of our service centers. You will find the addresses on our website: www.vatvalve.com.

6 Maintenance



Maintenance may only be carried out by the VAT service staff. In exceptional cases, the customer is allowed to carry out the maintenance, but only with the prior consent of VAT.

Please contact one of our service centers. You will find the addresses on our website www.vatvalve.com.

7 Repairs

Repairs may only be carried out by the VAT service staff. In exceptional cases, the customer is allowed to carry out the repairs, but only with the prior consent of VAT.


Please contact one of our service centers. You will find the addresses on our website www.vatvalve.com.

	<p style="text-align: center;">⚠ WARNING</p> <p>Unqualified personnel Inappropriate handling may cause serious injury or property damage. Only qualified personnel are allowed to carry out the described work.</p>
	<p style="text-align: center;">⚠ WARNING</p> <p>Danger of injury in case of insufficient skills Inappropriate handling may cause serious injury or property damage. Make sure that the valve does not topple or fall down while removing the protective covers from the flanges.</p>
	<p style="text-align: center;">NOTICE</p> <p>Contamination Product may get contaminated. Always wear cleanroom gloves when handling the product.</p>

7.1 Replacement of diaphragm

In case of a seat seal leak caused by environmental influences and no visible damage of the sealing surface at the seat, the diaphragm seal can be replaced.

VAT offers a range of components; see « Table 11-1 » on page 75. The seal exchange can be carried out by the user.




- | | |
|----|---------------|
| 1 | Valve body |
| 36 | Diaphragm |
| 60 | Disc spring |
| 61 | Bonnet screws |

Figure 7-1

Required material: Diaphragm

Ordering information: See chapter «11 Spare parts» on page 75.

NOTICE	
	<p>Inappropriate mounting position of valve</p> <p>Maintenance may be troublesome and parts may drop down.</p> <p>Ideally dismount valve from the system and put it on a clean workbench with the actuator upwards.</p>

Procedure:

The item numbers in brackets refer to «Figure 7-1» on page 68.

1. Open valve completely.
2. Loosen bonnet screws (61).
3. Remove valve body (1).
4. Remove disc spring (60).
5. Exchange diaphragm (36).



Check surfaces on its cleanliness and on damages.



Make sure that the sealing surface is free of scratches.

6. Insert disc spring (60) centered to the diaphragm (36).



Make sure that the disc spring (60) is assembled in the correct direction.

7. Clean valve body (1) with pure alcohol (Isopropanol), use a cleanroom wiper. Use oil free compressed air to blow off surfaces.
8. Assemble valve body (1) with caution. Tighten all bonnet screws (61) slowly in crosswise order with the following torque:

DN 16: 2.5 Nm

9. Open and close valve 5 times.

Valve is ready for use.

8 Dismounting and Storage

	WARNING
	<p>Unqualified personnel Inappropriate handling may cause serious injury or property damage. Only qualified personnel are allowed to carry out the described work.</p>


8.1 Dismounting


	WARNING
	<p>Harmful substances Risk of serious injury in case of contact with harmful substances. Remove harmful substances (e. g. toxic, caustic or microbiological) from the valve before dismounting.</p>

	NOTICE
	<p>Contamination Product may get contaminated. Always wear cleanroom gloves when handling the product.</p>

2. Close the valve
3. For dismounting the valve please follow the instructions of chapter: «Installation», however in reverse order.

8.2 Storage

NOTICE	
	<p>Wrong storage</p> <p>Inappropriate temperatures and humidity may cause damage to the product.</p> <p>Valve must be stored at:</p> <ul style="list-style-type: none">– relative humidity between 10% and 70%– temperature between +10 °C and +50 °C– non-condensing environment

NOTICE	
	<p>Inappropriate packaging</p> <p>Product may get damaged if inappropriate packaging material is used.</p> <p>Always use the original packaging material and handle product with care.</p>

1. Clean / decontaminate valve.
2. Cover all valve openings with a protective foil.
3. Pack valve appropriately, by using the original packaging material.

9 Packaging and Transport

	WARNING
	<p>Unqualified personnel Inappropriate handling may cause serious injury or property damage. Only qualified personnel are allowed to carry out the described work.</p>

	WARNING
	<p>Harmful substances Risk of serious injury in case of contact with harmful substances. Remove harmful substances (e. g. toxic, caustic or microbiological) from valve before you return the valve to VAT.</p>

	NOTICE
	<p>Inappropriate packaging Product may get damaged if inappropriate packaging material is used. Always use original packaging material and handle product with care.</p>



- When returning products to VAT, please fill out the VAT form «Declaration of Chemical Contamination of Vacuum Valves and Components» and send it to VAT in advance. The form can be downloaded from our website www.vatvalve.com (Section: Services – After sales).
- If products are radioactively contaminated, the VAT form «Contamination and Radiation Report» must be filled out. Please contact VAT in advance.
- If products are sent to VAT in contaminated condition, VAT will carry out the decontaminating procedure at the customer's expense.


9.1 Packaging

4. Cover all valve openings with a protective foil.
5. Pack valve appropriately, by using the original packaging material.



VAT disclaims any liability for damages resulting from inappropriate packaging.



9.2 Transport

	<p style="text-align: right;">NOTICE</p> <p>Inappropriate packaging Product may get damaged if inappropriate packaging material is used. Always use original packaging material and handle product with care.</p>
---	---




VAT disclaims any liability for damages resulting from inappropriate packaging.

10 Disposal

	 WARNING
	<p>Harmful substances Environmental pollution. Discard products and parts according to the local regulations.</p>

11 Spare parts

	NOTICE
	<p>Non-original spare parts</p> <p>Non-original spare parts may cause damage to the product. Use original spare parts from VAT only.</p>



- Please contact one of our service centers and specify the fabrication number of the product; see chapter «1.1 Identification of product». You will find the addresses on our website www.vatvalve.com.
- Parts may only be replaced by the VAT service staff.

Description	Item	Part No.	Quantity per valve	Repair procedure see chapter
Diaphragm	36	334578	1	«7.1 Replacement of diaphragm»

Table 11-1

12 Appendix



This Page Intentionally Left Blank